


AC 700

PIEZA Nº	CÓDIGO	DESCRIPCIÓN	MODELO	CANT.X MAQ.
1	411002	DEFLECTOR AC700	AC700	1
2	401012	TORN.ESTATOR AC700	AC700	2
3	405002	ESTATOR AC700	AC700	1
4	407004	CUERPO MOTOR AC700	AC700	1
6	409005	TAPA MANGO DER.AC700	AC700	1
7/8	401013	TORN.TAPA CUERPO AC700	AC700	7
8	417017	ARAND.PLANA TAPA AC700	AC700	8
	417018	ARAND.GROWER TAPA AC700	AC700	10
11/12	416002	PORTA ESCOBILLA AC700	AC700	2
10	401016	RESORTE ESCOBILLA AC700	AC700	2
13	401017	ESCOBILLA (JUEGO) AC700	AC700	1
17	416003	PERNO BISAGRA AC700	AC700	2
18	415002	CARRO PORTAHOJA AC700	AC700	2
19	401018	FIJADOR CARRO PORTAH.AC700	AC700	2
20	417019	ARAND.PRESION AC700	AC700	1
22	401019	TORN.CAJA AC700	AC700	8
23	402105	ROD.TRASMISION AC700	AC700	1
25	412013	CHAV.VOLANTE TRANSMISION AC700	AC700	1
26	412014	VOLANTE TRANSMISION AC700	AC700	1
27	412015	PLACA BALANCEADORA AC700	AC700	1
24	002102	ROD.AGUJAS AC700 (0810)	AC700	2
29	404003	ENG.SALIDA AC700	AC700	1
30	417024	SUPLEMENTO AC700	AC700	2
32	401026	ESPINA FIJACION ENG.AC700	AC700	1
34	401027	ESPINA FIJACION AC700	AC700	1
35	401023	TORN.CAJA ENGRANAJES AC700	AC700	2
36	401029	ESPINA CAJA ENG.SUP.AC700	AC700	2
37	410004	CAJA ENGRANAJES AC700	AC700	1
38/39/40/41	412016	REGULADOR ASPIRACION AC700	AC700	1
42	417023	ARAND.FIBRA AC700	AC700	1
44	002002	ROD.ROT.DELANTERO AC700 (6000)	AC700	1
45	406002	ROTOR C/VENT.AC700	AC700	1
	412017	PROTECTOR ROD.AC700	AC700	1
48/49	412018	PESTILLO SIERRA AC700	AC700	1
50	401020	TORN.CAVIDAD ENGRASADOR AC700	AC700	2
51	410005	CAJA TRANSMISION AC700	AC700	1
52	421004	RESORTE CAJA TRANSMISION AC700	AC700	1
53	424001	FIELTRO AC700	AC700	2
54	424002	MUELLE ACEITE AC700	AC700	1
55	412019	CAVIDAD ENGRASADOR AC700	AC700	1
56	427004	RETEN AC700	AC700	1
57	401031	FIJADOR RETEN AC700	AC700	1
59	412020	JUNTA CAJA ENGRANAJES AC700	AC700	1
60	417025	ANILLO SEG.VOL.TRANS.AC700	AC700	2
61	401021	TORN.VOLANTE TRANS.AC700	AC700	2
62	412021	LEVA PENDULO AC700	AC700	1
	420008	BUJE PLASTICO AC700	AC700	1
64	420009	BUJE GUIA AC700	AC700	1
65	412031	SOPORTE BUJE AC700	AC700	1
66	401028	ESPINA SOPORTE BUJE AC700	AC700	1
67	412022	ASPIRADOR POLVO AC700	AC700	1
68	401030	ESPINA CAJA ENG.INF.AC700	AC700	1
69	412023	PALANCA FIJACION BASE AC700	AC700	1
72	412024	PALANCA REGULA PENDULO AC700	AC700	1
73	414004	REGULADOR VELOCIDAD AC700	AC700	1

74	414005	INTERRUPTOR AC700	AC700	1
75	412025	CAPACITOR AC700	AC700	1
76	401022	TORN.PRENSACABLE AC700	AC700	2
77	412026	PRENSA CABLE AC700	AC700	1
78	002006	ROD.ROT.TRASERO AC700 (607)	AC700	1
80	412027	BOQ.PASACABLE AC700	AC700	1
81	419003	CABLE SALIDA AC700	AC700	1
83-91	412030	CAVIDAD SUJETA SIERRA AC700	AC700	1
92	426006	PROTECTOR ALAMBRE AC700	AC700	1
94	426008	PROTECTOR SUPERFICIES AC700	AC700	1
95	401025	TORN.CUBRE BASE AC700	AC700	4
96	412028	CUBRE BASE AC700	AC700	1
97	401024	TORN.PROTECTOR SUPERF.AC700	AC700	2
98	417022	ARAND.TUERCA AC700	AC700	2
100	423005	TUERCA PLANA AC700	AC700	1
101	412029	BASE AC700	AC700	1
103	409006	TAPA MANGO IZQ.AC700	AC700	1



AC 700_ Explosión