

### BT 12V / BT 220V

PIEZA Nº	CÓDIGO	DESCRIPCIÓN	MODELO	CANT.X MAQ.
1	132002	TAPA ROSCA ENTRADA BT	BT12V-220V	1
2	001310	TORN.CABEZAL BT	BT12V-220V	4
3	130002	CABEZAL DOS BOCAS BT	BT12V-220V	1
4	027107	ORING TORN.PURGA BT	BT12V-220V	1
5	001320	TORN.PURGA BT	BT12V-220V	1
6	132012	TAPA ROSCA SUPERIOR BT	BT12V-220V	1
7	132004	PALETA BT	BT12V-220V	1
8	027109	ORING CUERPO BT	BT12V-220V	1
9	001312	TORN.CUERPO BT	BT12V-220V	4
10	009020	TAPA CUERPO BT	BT12V-220V	1
11	023020	TUERCA TAPA CUERPO BT	BT12V-220V	4
12	132006	CUBETA SELLO CERAMICO BT	BT12V-220V	1
13	132008	ARAND.SELLO CERAMICO BT	BT12V-220V	1
14	132010	SELLO CERAMICO BT	BT12V-220V	1
15	132014	TAPA MOTOR DEL. BT	BT12V-220V	1
16	002007	ROD.ROTOR DEL. BT (6201)	BT12V-220V	1
17A	006014	ROTOR C/VENT.BT12V	BT12V	1
17B	132022	VENTILADOR BT	BT12V-220V	1
18	001322	VARILLA ROSCADA BT	BT12V-220V	2
19	002007	ROD.ROTOR TRAS. BT (6201)	BT12V-220V	1
20	007010	CUERPO MOTOR BT	BT12V-220V	1
21	132020	BORNERA BT	BT12V-220V	1
22	009016	TAPA CONEXIÓN BT	BT12V-220V	1
23	001314	TORN.TAPA BT	BT12V-220V	2
24	119008	CABLE CONEXIÓN BT	BT12V-220V	1
25	132016	BASE CHAPA BT	BT12V-220V	1
26	001316	TORN.BASE CHAPA BT	BT12V-220V	4
27	005011	ESTATOR BT12V	BT12V	1
28	015014	TUERCA ESTATOR BT	BT12V-220V	2
29	132024	RESORTE ESCOBILLA BT	BT12V-220V	2
30	015010	ESCOBILLA (JUEGO) BT12V	BT12V	1
31	132018	PORTA ESCOBILLA BT	BT12V-220V	1
32	132026	TAPA MOTOR TRAS. BT	BT12V-220V	1
33	023020	TUERCA TAPA MOTOR BT	BT12V-220V	2
34	132028	TAPA PLASTICA TRAS. BT	BT12V-220V	1
35	001318	TORN.TAPA PLASTICA TRAS. BT	BT12V-220V	1
17A	006016	ROTOR C/VENT. BT220V	BT220V	1
27	005012	ESTATOR BT220V	BT220V	1
30	015012	ESCOBILLA (JUEGO) BT220V	BT220V	1

# BT 220V - BT 12V\_Explosión

