

CS 150

PIEZA Nº	CÓDIGO	DESCRIPCIÓN	MODELO	CANT.X MAQ.
1	401001	TORN.TAPA MOTOR CS150	CS150	4
2	409001	TAPA MOTOR CS150	CS150	1
3	401002	TORN.TAPA MANGO IZQ.CS150	CS150	8
4	401003	TORN.TAPA MANGO IZQ.CS150	CS150	3
5	409002	TAPA MANGO IZQUIERDA CS150	CS150	1
7	401004	TORN.PUÑO SUPERIOR CS150	CS150	2
8	408001	PUÑO SUPERIOR CS150	CS150	1
11	401005	TORN.PUÑO SUPERIOR AUX.CS150	CS150	2
12	408002	PUÑO INFERIOR CS150	CS150	1
13	405001	ESTATOR CS150	CS150	1
14	411001	DEFLECTOR CS150	CS150	1
15	414001	INTERRUPTOR CS150	CS150	1
17	409003	TAPA MANGO DERECHA CS150	CS150	1
18	002002	ROD.ROT.TRASERO CS150 (6000)	CS150	1
19	412001	PROTECTOR ROD.CS150	CS150	1
20	406001	ROTOR C/VENT.CS150	CS150	1
21	419001	CABLE SALIDA CS150	CS150	1
22	412002	SUJETA CABLE CS150	CS150	1
23	401006	TORN.SUJETA CABLE CS150	CS150	2
24	412003	PASACABLE CS150	CS150	1
25	412004	CONDENSADOR CS150	CS150	1
26	401007	TORN.CUERPO MOTOR CS150	CS150	2
27	407001	CUERPO MOTOR CS150	CS150	1
28	417001	ARAND.PLANA CUERPO MOTOR CS150	CS150	3
29	417002	ARAND.GROWER CUERPO M.CS150	CS150	3
30	401008	TORN.CUERPO MOTOR CS150	CS150	3
31	421001	RESORTE PORTAESCOBILLA CS150	CS150	2
32	416001	PORTA ESCOBILLA CS150	CS150	2
33	415001	ESCOBILLA (JUEGO) CS150	CS150	2
34	409007	TAPA PORTAESCOBILLA CS150	CS150	2
35	002108	ROD.ROT.DELANTERO CS150 (6001)	CS150	1
36	427001	ORING CS150	CS150	1
37	412005	BOTON TRABADISCO CS150	CS150	1
38	412006	PERNO TRABADISCO CS150	CS150	1
39	417003	ARAND.CUERPO MOTOR CS150	CS150	1
40	417011	ANILLO SEG.TRABA DISCO CS150	CS150	1
41	420001	BUJE PERNO TRABADISCO CS150	CS150	1
42	401009	TORN.CUERPO MOTOR AUX.L.CS150	CS150	1
43	417004	ARAND.GROWER CUERPO M.AUX.CS150	CS150	7
44	401010	TORN.CUERPO MOTOR AUX.C.CS150	CS150	4
45	417005	ARAND.PLANA CUERPO MOTOR AUX.CS	CS150	4
50	423001	BLOQUEO GOMA CS150	CS150	1
51	417006	ARAND.PLANA CAJA ENG.CS150	CS150	1
52	401014	TORN.BLOQUEO GOMA CS150	CS150	1
53	002006	ROD.ENG.SALIDA CS150 (607)	CS150	1
54	417012	ANILLO SEG.EJE SALIDA CS150	CS150	1
55	404001	ENG.SALIDA CS150	CS150	1
56	412007	CHAV.EJE SALIDA CS150	CS150	1
57	403001	EJE SALIDA CS150	CS150	1
58	002007	ROD.EJE SALIDA CS150 (6201)	CS150	1
59	417007	ANILLO SEG.TAPA SALIDA CS150	CS150	1
60	409004	TAPA SALIDA CS150	CS150	1

61/87	401015	TORNILLO TAPA SALIDA CS150	CS150	5
62	412008	CUBRESIERRA CS150	CS150	1
63	417008	ANILLO SEG.CUBRESIERRACS150	CS150	1
64	426003	BRIDA INTERIOR CS150	CS150	1
65	426007	SIERRA CIRCULAR CS150	CS150	1
66	426004	BRIDA EXTERIOR CS150	CS150	1
67	401032	BULON SIERRA CIRCULAR CS150	CS150	1
68	401011	TORN.BOTON CUBRESIERRA CS150	CS150	1
69	412009	BOTON CUBRESIERRA CS150	CS150	1
70	401033	BULON BASE CS150	CS150	1
71	417009	ARAND.BASE CS150	CS150	3
72	423002	MARIPOSA FIJ.ANGULO CS150	CS150	2
73	401034	BULON MARIPOSA CS150	CS150	2
74	423003	MARIPOSA CORTE RECTO CS150	CS150	1
75	421002	RESORTE MARIPOSA CS150	CS150	1
76	412010	BASE CS150	CS150	1
77	401035	BULON BASE LATERAL CS150	CS150	1
78	421003	RESORTE LARGO CS150	CS150	1
79	401036	BULON BOTON AJUSTE CS150	CS150	1
80	410001	CAJA ENGRANAJES CS150	CS150	1
81	423004	TUERCA FIJACION CS150	CS150	1
82	412011	BOTON AJUSTE CS150	CS150	1
83	417010	ANILLO SEG.BOTON AJUSTE CS150	CS150	1
84	426005	ACCESORIO CORTE RECTO CS150	CS150	1
86	420007	BOQUILLA ASPIRACION CS150	CS150	1

CS 150_Explosión

